


U.S. FDA UNIQUE DEVICE IDENTIFICATION (UDI)

Quick Reference Guide to GS1 Identifiers & Barcodes



LEARNING THE TERMS FDA UDI GS1 STANDARDS FDA UDI GS1 Standards Unique Device Identification **Product Identification** Labeler **Brand Owner** One who applies or modifies the label with intent to put device into commercial distribution FDA Device Identifier (DI) GS1 Global Trade Item Number® (GTIN®) **Dynamic Data (PI) Dynamic Data (AI)** FDA Production Identifier (PI) GS1 Application Identifier (AI) (if applicable) • Batch/Lot Number: AI(10) • Production Date: AI(11) • Expiration Date: AI(17) • Serial Number: AI(21)



LEARNING THE TERMS

Machine
Readable
Data Carrier

Linear
Barcode

GS1
DataMatrix

RFID

Automatic
Identification and
Data Capture

EXAMPLES OF DI WITH PI IN GS1 STANDARD FORMAT*

GTIN with Expiration Date, Lot & Serial encoded in a GS1-128 Barcode

GTIN with Serial, Lot & Expiration Date

encoded in a GS1 DataBar® (Stacked) & Composite

(17) 101231 (10) 987654321GFEDCBA (21) ABCDEFG123456789

) 0 0 3 1 4 1 4 1 9 9 9 9 9 5

GTIN with Lot Number & Expiration Date encoded in a GS1-128 Barcode

GTIN with Lot Number encoded in a GS1-128 Barcode







GTIN with Expiration Date and Serial

Number encoded in a GS1 DataMatrix



*Individual manufacturers select the data encoded based on their control procedures

MEDICAL PACKAGING LEVELS


There should be a Unique Device Identification at every level of packaging except at the logistic unit level.



614141999996

DI + PI = FDA UDI





GS1 GTIN or GTIN + AI = UDI

ITEM ▶ NEW ▶ INNER PACK ▶ NEW ▶ CASE

MEDICAL PACKAGING LEVELS

Global Unique

Device Identification

Database

When possible, barcodes are to be displayed on the product packages to allow ready access to scanning equipment when the product is stored or stocked on shelves.

- Orientation: The barcode is to be displayed on the package so the human readable portion is oriented to read from the same direction as other labeling information.
- Display Panel: Barcodes are to be displayed on the panel or label most likely to be facing out on the shelf when the package is stored.

Unique Device

Identification



The most common reasons for a GTIN

to change are:

WHY DO GTINS CHANGE?

Change in the specifications, performance, size, or composition of the device to an extent greater than the specified limits

 Change in quantity of a device package or addition of a new device package

(this includes the package itself)

- Change from a non-sterile package to a sterile package, or from a sterile package to a non-sterile package
- Re-labeling of the original labeler's device
- Change in labeling languages for different global markets
- Change in certification mark, e.g., CE Mark
- Change to outside package dimensions

NOTES & TOOLS

Notes

- Symbols are not to scale and are for illustration purposes only
- U.P.C., EAN-13, and ITF-14 cannot encode Application Identifiers

Reference Tools

- Implementation Guideline for FDA UDI
- GS1 General Specifications
- FDA UDI FAQs
- GS1 Healthcare GTIN Allocation Rules
- Healthcare Provider & Supplier GTIN Tool Kits
- www.gs1us.org/hcudi
- www.fda.gov

Disclaimer

This document is intended to demonstrate the use of GS1 Standards for UDI. It does not provide any guidance or advice regarding regulatory compliance. Please consult your internal regulatory staff for compliance questions.

Contact

GS1 Healthcare US® www.gs1us.org/healthcare

T +1 937.435.3870

GS1 is an FDA UDI Issuing Agency.

© 2014 GS1 US ALL RIGHTS RESERVED